R&S®ESSENTIALS

R&S[®]ZNLE VECTOR NETWORK ANALYZER

Measurements as easy as ABC



Product Brochure Version 07.00

ROHDE&SCHWARZ

Make ideas real



warranty

AT A GLANCE

The R&S[®]ZNLE makes vector network analyzer measurements as easy as ABC: easy to configure, easy to calibrate, easy to measure. The renowned high-quality design, an innovative user interface and its compact size make the R&S[®]ZNLE ideal for basic VNA applications.

The R&S®ZNLE is a two-port vector network analyzer that can be used for bidirectional measurements of S-parameters S₁₁, S₂₁, S₁₂ and S₂₂ on passive components.

Configuring the R&S[®]ZNLE requires only three decisions:

- ► Choose the frequency range
- ► Decide whether you need a GPIB interface
- Decide whether you need to perform time domain analysis or distance-to-fault measurements

The analyzer is available with a frequency range from 100 kHz (with R&S[®]ZNLE-B100 option) up to 20 GHz (R&S®ZNLE18 in overrange). The optional GPIB interface lets you connect a controller to remotely control the R&S®ZNLE.

As a standalone instrument, the R&S[®]ZNLE does not require an external PC to configure the setup. You can start measuring immediately after you switch on the instrument. The time domain analysis option (R&S[®]ZNL-K2) and distance-to-fault measurements option (R&S[®]ZNL-K3) enhance the R&S®ZNLE with essential features for general purpose testing.

KEY FEATURES

- ► Frequency range from 100 kHz to 20 GHz (R&S[®]ZNLE18 in overrange)
- ► Two-port vector network analyzer with a full S-parameter test set for bidirectional measurements on passive components
- ► Wide dynamic range of up to typ. 120 dB
- Measurement bandwidths from 1 Hz to 500 kHz
- ► Fast measurements, i.e. 8.7 ms for 401 points (100 kHz IFBW, 200 MHz span, correction off)
- ► Compact size (depth of 24 cm) and low weight (6 kg)
- Standalone instrument with 10.1" WXGA touchscreen
- Windows 10 operating system



BENEFITS

An economical instrument with solid performance ► page 4

User interface with multitouch screen ▶ page 5

Clearly structured user interface ▶ page 6

Standard instrument for use in a lab ▶ page 8

AN ECONOMICAL INSTRUMENT WITH SOLID PERFORMANCE

USER INTERFACE WITH MULTITOUCH SCREEN

The R&S[®]ZNLE is a plug & play vector network analyzer containing everything needed to start a measurement. With a fully integrated powerful PC platform running the Windows 10 operating system, the R&S[®]ZNLE is a complete standalone analyzer. The solid-state hard disk delivers fast boot time and the reliability required for demanding applications. Configure measurements right on the R&S[®]ZNLE and save valuable bench space since there is no need for a mouse, keyboard and external monitor. Simply plug in the instrument and start measuring.

Compact vector network analyzer

Vector network analyzers such as the R&S®ZNLE characterize electronic networks by measuring the magnitude and phase of S-parameters. Featuring an instrument depth of less than 24 cm and weighing only around 6 kg, the R&S®ZNLE is the most compact instrument in its class.

Low trace noise for high accuracy

The R&S®ZNLE offers a low trace noise of typ. 0.001 dB (at 10 kHz measurement bandwidth). This allows highly accurate, stable and repeatable measurements even at wider IF bandwidths. Using larger measurement bandwidths, the R&S®ZNLE can perform faster measurements while delivering excellent trace stability.

High measurement speed

The R&S[®]ZNLE is up to 10 times faster than similar instruments. With a measurement speed of 9.6 ms for 201 points (100 kHz IFBW, 200 MHz span, full two-port calibration) and fast LAN or IEC/IEEE data transfer, the R&S[®]ZNLE meets the speed requirements encountered in production and in everyday testing.

Wide 10.1" WXGA multitouch screen

The wide 10.1" multitouch screen is perfect for displaying setups and arranging measurements as required by the current application. Simply drag&drop to adapt the layout to your needs. The multitouch capability of the R&S®ZNLE lets you do more than just move the traces around with the touch of a finger. You can also use gesturing to zoom in and out.

Thanks to the fully integrated help menu, help is just a **Clearly structured user interface** click away. In every dialog window, the R&S®ZNLE has a The R&S[®]ZNLE features a user interface that is simple and help button that takes you directly to the relevant section clearly structured. Configure measurements in just a few of the user manual. The help softkey is located on the left steps. Drag and drop traces, channels and diagrams to side of the display and can be accessed at any time. An achieve your ideal layout. Save, reload and switch between integrated search function lets you guickly find different different setups by tapping on the touchscreen. topics and functions.

Overview of the R&S®ZNLE user interface. Here the wizard for easy configuration of S-parameters and the context-sensitive help menu are open



Comparison of footprint of different VNAs



Undo/redo softkey for user-friendly operation

Use the undo and redo softkeys to cancel and restore measurement configurations. Check the influence of a measurement setting and revise it guickly, without having to reconfigure the entire measurement. To restart a setup from scratch, just press the Preset key.

Fully integrated context-sensitive help menu

CLEARLY STRUCTURED USER INTERFACE



STANDARD INSTRUMENT FOR USE IN A LAB

In development, it is often necessary to measure passive components quickly. The R&S[®]ZNLE not only delivers solid RF performance, it also offers features that make your life easier.

Calibration units for quick calibration

The R&S[®]ZNLE calibration wizard guides you through the calibration process. Manual calibration kits and automatic calibration units are supported.

The analyzer's automatic calibration unit minimizes the time needed to perform full system error correction. The calibration unit is ready for use right after it is connected to the R&S[®]ZNLE. It only takes a few steps to calibrate the setup. This is especially an advantage in production environments, helping you save time and maximize throughput.

The following calibration procedures are available:

- ► Reflection normalization open or short
- ► Reflection OSM (OSL)
- Enhanced reflection normalization OM or SM
- Transmission normalization (response calibration)
- Transmission normalization both (response calibration)
- One path, two ports
- ► TOSM (SOLT)
- UOSM (only with calibration unit)
- ► TRL



The configurable R&S[®]ZN-ZE104, R&S[®]ZN-ZE109, R&S[®]ZN-ZE118 and R&S[®]ZN-ZE126 calibration units provide great performance in a compact, lightweight and economic solution.

Calibration accessories are also portable

The R&S[®]ZN-Z1xx series two-port economy calibration units are not only robust but also lightweight and easily carried in a transport bag or on a neck strap. If you are looking to simplify calibration, reduce operator error and improve calibration repeatability, the R&S[®]ZN-ZE1xx economy calibration units are the perfect choice and also offer the convenience of portability. The flexible connector configuration concept lets users address all use cases for which N-type, 3.5 mm or 2.92 mm connectors are needed, for frequencies ranging from 5 kHz to 26.5 GHz.

De/embedding functionality and fixture compensation

It is often necessary to characterize single components that are specified together with a matching network. The R&S[®]ZNLE can embed the DUT into virtual matching networks to achieve realistic conditions when simulating the DUT in its operational environment. The R&S[®]ZNLE offers a choice of predefined matching network topologies. It is also possible to read *.snp files into the R&S[®]ZNLE and use them for deembedding/embedding.

The fixture compensation feature corrects the measurement results by compensating for the effect of a test fixture.

Time domain analysis and distance-to-fault (DTF) measurements

Some measurements require the characterization of a specific component of a composite DUT (for example an antenna of an IoT device). With the R&S°ZNL-K2 option, the R&S°ZNLE lets you analyze the DUT in the time domain and use the time gating function to isolate the required circuit section.

The distance-to-fault measurements option (R&S°ZNL-K3) lets you detect cable discontinuities, which is important for example for base station antenna installation. You can select from a range of common cable types with





The calibration wizard provides an overview of the possible calibration methods for easy selection.

predefined velocity factor and frequency-dependent attenuation, or create your own cable profiles. The R&S®ZNL-K2 and R&S®ZNL-K3 options use internal DC extrapolation. The optional frequency extension down to 100 kHz (R&S®ZNLE-B100) is helpful as it provides improved accuracy.

Remote controllable with LAN and GPIB option

The R&S[®]ZNLE can be remote controlled via the integrated LAN interface. The optional GPIB interface lets you connect a controller to remotely control the R&S[®]ZNLE. Data is transmitted bidirectionally on the 8-bit parallel bus. The data measured during a sweep is transferred to the controller while the next sweep is in progress. As a result, the R&S[®]ZNLE has virtually negligible data transfer time.

The fixture compensation menu offers a good overview of all available compensation methods.

SPECIFICATIONS IN BRIEF

Specifications in brief		
Frequency range	R&S®ZNLE3	100 kHz ¹⁾ /1 MHz to 3 GHz
	R&S [®] ZNLE4	100 kHz ¹⁾ /1 MHz to 4.5 GHz
	R&S [®] ZNLE6	100 kHz ¹⁾ /1 MHz to 6 GHz
	R&S®ZNLE14	100 kHz ¹⁾ /1 MHz to 14 GHz
	R&S [®] ZNLE18	100 kHz $^{\mbox{\tiny 1)}}/1$ MHz to 18 GHz (20 GHz overrange)
Measurement time	201 points, 100 kHz IFBW, 200 MHz span, full two-port calibration	9.6 ms
Data transfer time	IEC/IEEE (201 points)	typ. 3.0 ms
	HiSLIP with 1 Gbit/s LAN	typ. 2.5 ms
Dynamic range	10 Hz measurement bandwidth	up to typ. 120 dB
Output power		up to typ. +2 dBm
Measurement bandwidths		selectable in steps of 1/1.5/2/3/5/7 · 1 Hz/10 Hz/ /100 kHz; max. upper limit: 500 kHz
Frequency resolution		1 Hz
Measurement points per trace		1 to 5001
Operating system		Windows 10

¹⁾ With R&S[®]ZNLE-B100 option.

The R&S®ZNLE saves a lot of space on the workbench for measurements setups, e.g. to tune filters.



ORDERING INFORMATION

Designation		
Base unit		
Vector network analyzer, 1 MHz to 3 GHz, two ports, N (f)		
Vector network analyzer, 1 MHz to 4.5 GHz, two ports, N (f)		
Vector network analyzer, 1 MHz to 6 GHz, two ports, N (f)		
Vector network analyzer, 1 MHz to 14 GHz, two ports, N (f)		
Vector network analyzer, 1 MHz to 18 GHz (20 GHz overrange), two por		
Options		
Extended frequency range, lower end, 1 MHz to 100 kHz		
GPIB interface		
Time domain analysis		
Distance-to-fault measurements		
Recommended extras		
Calibration kits		
Calibration kit, N (m), 50 Ω , 0 Hz to 18 GHz		
Calibration kit, N (f), 50 $\Omega,$ 0 Hz to 18 GHz		
Calibration kit, 3.5 mm (m), 50 $\Omega,$ 0 Hz to 26.5 GHz		
Calibration kit, 3.5 mm (f), 50 $\Omega,$ 0 Hz to 26.5 GHz		
Calibration units		
Calibration unit, 1 port, N (f), 2 MHz to 4 GHz		
Calibration unit, 1 port, N (f), 1 MHz to 6 GHz		
Calibration unit, 2 configurable ports, 5 kHz to 4.5 GHz		
Calibration unit, 2 configurable ports, 5 kHz to 9 GHz		
Calibration unit, 2 configurable ports, 5 kHz to 18 GHz		
Calibration unit, 2 configurable ports, 5 kHz to 26.5 GHz		
Cables		
N (m) to N (m), 50 $\Omega,$ length: 0.6 m/0.9 m, 0 Hz to 18 GHz		
N (m) to 3.5 mm (m), 50 $\Omega,$ length: 0.6 m/0.9 m, 0 Hz to 18 GHz		
3.5 mm (f) to 3.5 mm (m), 50 $\Omega,$ length: 0.6 m/0.9 m, 0 Hz to 26.5 GHz		
Accessories		
Protective hard cover		
Transport bag, transparent cover		
Carrying vest holster		
Anti-glare film		
Rackmount kit		

	3 years
	1 year
R&S®WE1	Please contact your local Rohde&Schwarz sales office.
R&S®WE2	
R&S [®] CW1	
R&S [®] CW2	
R&S®AW1	
R&S®AW2	
	R&S®WE2 R&S®CW1 R&S®CW2 R&S®AW1

¹⁾ For options installed, the remaining base unit warranty applies if longer than 1 year. Exception: all batteries have a 1 year warranty.

	Туре	Order No.
	R&S [®] ZNLE3	1323.0012.53
	R&S [®] ZNLE4	1323.0012.54
	R&S [®] ZNLE6	1323.0012.56
	R&S [®] ZNLE14	1323.0012.64
, N (f)	R&S [®] ZNLE18	1323.0012.70
	R&S [®] ZNLE-B100	1303.9272.02
	R&S [®] FPL1-B10	1323.1890.02
	R&S [®] ZNL-K2	1323.1819.02
	R&S®ZNL-K3	1323.1825.02
	R&S [®] ZN-Z170	1328.8163.02
	R&S [®] ZN-Z170	1328.8163.03
	R&S°ZN-Z135	1328.8157.02
	R&S®ZN-Z135	1328.8157.03
	R&S [®] ZN-Z103	1321.1828.02
	R&S°ZN-Z103	1321.1828.12
	R&S [®] ZN-ZE104	1350.8040.04
	R&S [®] ZN-ZE109	1350.8040.09
	R&S®ZN-ZE118	1350.8040.18
	R&S®ZN-ZE126	1350.8040.26
	R&S®ZV-Z191	1306.4507.24/36
	R&S®ZV-Z192	1306.4513.24/36
	R&S°ZV-Z193	1306.4520.24/36
	R&S®FPL1-Z1	1323.1960.02
	R&S [®] FPL1-Z2	1323.1977.02
	R&S®FPL1-Z3	1323.1683.02
	R&S [®] FPL1-Z5	1323.1690.02
	R&S®FPL1-Z6	1323.1954.02